

RUSH HIPRO SANDAL TOE FOOT SHELL

Art.nr.	Modell	Lev.art.nr.
759082231	RUSH Hipro Sandal Toe Foot Shell 22cm Left Dark	FTC-4R-122D4-SL
759082232	RUSH Hipro Sandal Toe Foot Shell 22cm Right Dark	FTC-4R-122D4-SR
759082211	RUSH Hipro Sandal Toe Foot Shell 22cm Left Light	FTC-4R-122L4-SL
759082212	RUSH Hipro Sandal Toe Foot Shell 22cm Right Light	FTC-4R-122L4-SR
759082221	RUSH Hipro Sandal Toe Foot Shell 22cm Left Medium	FTC-4R-122M4-SL
759082222	RUSH Hipro Sandal Toe Foot Shell 22cm Right Medium	FTC-4R-122M4-SR
759082331	RUSH Hipro Sandal Toe Foot Shell 23cm Left Dark	FTC-4R-123D4-SL
759082332	RUSH Hipro Sandal Toe Foot Shell 23cm Right Dark	FTC-4R-123D4-SR
759082311	RUSH Hipro Sandal Toe Foot Shell 23cm Left Light	FTC-4R-123L4-SL
759082312	RUSH Hipro Sandal Toe Foot Shell 23cm Right Light	FTC-4R-123L4-SR
759082321	RUSH Hipro Sandal Toe Foot Shell 23cm Left Medium	FTC-4R-123M4-SL
759082322	RUSH Hipro Sandal Toe Foot Shell 23cm Right Medium	FTC-4R-123M4-SR
759082431	RUSH Hipro Sandal Toe Foot Shell 24cm Left Dark	FTC-4R-124D4-SL
759082432	RUSH Hipro Sandal Toe Foot Shell 24cm Right Dark	FTC-4R-124D4-SR
759082411	RUSH Hipro Sandal Toe Foot Shell 24cm Left Light	FTC-4R-124L4-SL
759082412	RUSH Hipro Sandal Toe Foot Shell 24cm Right Light	FTC-4R-124L4-SR
759082421	RUSH Hipro Sandal Toe Foot Shell 24cm Left Medium	FTC-4R-124M4-SL
759082422	RUSH Hipro Sandal Toe Foot Shell 24cm Right Medium	FTC-4R-124M4-SR
759082531	RUSH Hipro Sandal Toe Foot Shell 25cm Left Dark	FTC-4R-125D4-SL
759082532	RUSH Hipro Sandal Toe Foot Shell 25cm Right Dark	FTC-4R-125D4-SR
759082511	RUSH Hipro Sandal Toe Foot Shell 25cm Left Light	FTC-4R-125L4-SL
759082512	RUSH Hipro Sandal Toe Foot Shell 25cm Right Light	FTC-4R-125L4-SR
759082521	RUSH Hipro Sandal Toe Foot Shell 25cm Left Medium	FTC-4R-125M4-SL
759082522	RUSH Hipro Sandal Toe Foot Shell 25cm Right Medium	FTC-4R-125M4-SR
759082631	RUSH Hipro Sandal Toe Foot Shell 26cm Left Dark	FTC-4R-126D4-SL
759082632	RUSH Hipro Sandal Toe Foot Shell 26cm Right Dark	FTC-4R-126D4-SR
759082611	RUSH Hipro Sandal Toe Foot Shell 26cm Left Light	FTC-4R-126L4-SL
759082612	RUSH Hipro Sandal Toe Foot Shell 26cm Right Light	FTC-4R-126L4-SR
759082621	RUSH Hipro Sandal Toe Foot Shell 26cm Left Medium	FTC-4R-126M4-SL
759082622	RUSH Hipro Sandal Toe Foot Shell 26cm Right Medium	FTC-4R-126M4-SR
759082731	RUSH Hipro Sandal Toe Foot Shell 27cm Left Dark	FTC-4R-127D4-SL
759082732	RUSH Hipro Sandal Toe Foot Shell 27cm Right Dark	FTC-4R-127D4-SR
759082711	RUSH Hipro Sandal Toe Foot Shell 27cm Left Light	FTC-4R-127L4-SL
759082712	RUSH Hipro Sandal Toe Foot Shell 27cm Right Light	FTC-4R-127L4-SR
759082721	RUSH Hipro Sandal Toe Foot Shell 27cm Left Medium	FTC-4R-127M4-SL
759082722	RUSH Hipro Sandal Toe Foot Shell 27cm Right Medium	FTC-4R-127M4-SR
759082831	RUSH Hipro Sandal Toe Foot Shell 28cm Left Dark	FTC-4R-128D4-SL
759082832	RUSH Hipro Sandal Toe Foot Shell 28cm Right Dark	FTC-4R-128D4-SR
759082811	RUSH Hipro Sandal Toe Foot Shell 28cm Left Light	FTC-4R-128L4-SL
759082812	RUSH Hipro Sandal Toe Foot Shell 28cm Right Light	FTC-4R-128L4-SR
759082821	RUSH Hipro Sandal Toe Foot Shell 28cm Left Medium	FTC-4R-128M4-SL
759082822	RUSH Hipro Sandal Toe Foot Shell 28cm Right Medium	FTC-4R-128M4-SR
759082931	RUSH Hipro Sandal Toe Foot Shell 29cm Left Dark	FTC-4R-129D4-SL
759082932	RUSH Hipro Sandal Toe Foot Shell 29cm Right Dark	FTC-4R-129D4-SR
759082911	RUSH Hipro Sandal Toe Foot Shell 29cm Left Light	FTC-4R-129L4-SL
759082912	RUSH Hipro Sandal Toe Foot Shell 29cm Right Light	FTC-4R-129L4-SR
759082921	RUSH Hipro Sandal Toe Foot Shell 29cm Left Medium	FTC-4R-129M4-SL
759082922	RUSH Hipro Sandal Toe Foot Shell 29cm Right Medium	FTC-4R-129M4-SR