

RUSH ROVER FOOT SHELL

Art.nr.	Modell	Lev.art.nr.
759522110	RUSH ROVER FOOTSHELL 22CM LEFT LIGHT	FSK-22-L1
759522210	RUSH ROVER FOOTSHELL 22CM LEFT DARK	FSK-22-L3
759522120	RUSH ROVER FOOTSHELL 22CM RIGHT LIGHT	FSK-22-R1
759522220	RUSH ROVER FOOTSHELL 22CM RIGHT DARK	FSK-22-R3
759523110	RUSH ROVER FOOTSHELL 23CM LEFT LIGHT	FSK-23-L1
759523210	RUSH ROVER FOOTSHELL 23CM LEFT DARK	FSK-23-L3
759523120	RUSH ROVER FOOTSHELL 23CM RIGHT LIGHT	FSK-23-R1
759523220	RUSH ROVER FOOTSHELL 23CM RIGHT DARK	FSK-23-R3
759524110	RUSH ROVER FOOTSHELL 24CM LEFT LIGHT	FSK-24-L1
759524210	RUSH ROVER FOOTSHELL 24CM LEFT DARK	FSK-24-L3
759524120	RUSH ROVER FOOTSHELL 24CM RIGHT LIGHT	FSK-24-R1
759524220	RUSH ROVER FOOTSHELL 24CM RIGHT DARK	FSK-24-R3
759525110	RUSH ROVER FOOTSHELL 25CM LEFT LIGHT	FSK-25-L1
759525210	RUSH ROVER FOOTSHELL 25CM LEFT DARK	FSK-25-L3
759525120	RUSH ROVER FOOTSHELL 25CM RIGHT LIGHT	FSK-25-R1
759525220	RUSH ROVER FOOTSHELL 25CM RIGHT DARK	FSK-25-R3
759526110	RUSH ROVER FOOTSHELL 26CM LEFT LIGHT	FSK-26-L1
759526210	RUSH ROVER FOOTSHELL 26CM LEFT DARK	FSK-26-L3
759526120	RUSH ROVER FOOTSHELL 26CM RIGHT LIGHT	FSK-26-R1
759526220	RUSH ROVER FOOTSHELL 26CM RIGHT DARK	FSK-26-R3
759527110	RUSH ROVER FOOTSHELL 27CM LEFT LIGHT	FSK-27-L1
759527210	RUSH ROVER FOOTSHELL 27CM LEFT DARK	FSK-27-L3
759527120	RUSH ROVER FOOTSHELL 27CM RIGHT LIGHT	FSK-27-R1
759527220	RUSH ROVER FOOTSHELL 27CM RIGHT DARK	FSK-27-R3
759528110	RUSH ROVER FOOTSHELL 28CM LEFT LIGHT	FSK-28-L1
759528210	RUSH ROVER FOOTSHELL 28CM LEFT DARK	FSK-28-L3
759528120	RUSH ROVER FOOTSHELL 28CM RIGHT LIGHT	FSK-28-R1
759528220	RUSH ROVER FOOTSHELL 28CM RIGHT DARK	FSK-28-R3
759529110	RUSH ROVER FOOTSHELL 29CM LEFT LIGHT	FSK-29-L1
759529210	RUSH ROVER FOOTSHELL 29CM LEFT DARK	FSK-29-L3
759529120	RUSH ROVER FOOTSHELL 29CM RIGHT LIGHT	FSK-29-R1
759529220	RUSH ROVER FOOTSHELL 29CM RIGHT DARK	FSK-29-R3
759530110	RUSH ROVER FOOTSHELL 30CM LEFT LIGHT	FSK-30-L1
759530210	RUSH ROVER FOOTSHELL 30CM LEFT DARK	FSK-30-L3
759530120	RUSH ROVER FOOTSHELL 30CM RIGHT LIGHT	FSK-30-R1
759530220	RUSH ROVER FOOTSHELL 30CM RIGHT DARK	FSK-30-R3